

MAINTENANCE PLAN

Break in Period			Maintenance	Every
300 m 500 km	1500 m 2500 km	3000 m 5000 km		
			Clean air filter Check V-belt tension Clean fuel system, check carburetor adjustment Check contact breaker points and ignition timing Check valve clearance Check compression Check spark plugs Check battery Check cables and connections of electrical system and generator Check front wheel bearings, torsion arm link pins, steering and toe-in Check tire pressure, check wheel nuts for tight fit Check foot and parking brake, check all tube and hose connections for leaks, check brake fluid level Check correct fit and effectiveness of shock absorbers Check clutch pedal travel Check rear axle and engine for leaks	3000 miles (5000 km)
			Exhaust, intake manifold, carburetor and fuel pump Engine, transmission, rear axle and front axle, steering Remove brake drums and check brake linings	Check bolts and nuts for tight fit 6000 miles (10000 km)