

Headrests

General

Two mounting brackets on the seat frame as shown below are standard on all seats so that headrests can be installed. The outer brackets are fastened to these inner mounts through the upholstery by two B 4.9 x 16 DIN 7973 screws each.

Dimensions

- A = 15 mm
- B = 8 mm
- C = 44 mm
- D = 3.5 mm dia.

Installation

1. Locate the inside brackets by pressing on the upholstery of the backrest.
2. Using a punch, locate the screw holes in the brackets.
3. Fasten the outer brackets with two screws each.
4. Install headrests and adjust position with the set screws.

