

- Rotate the crankshaft pully one half revolution (exactly 180°) counter clockwise and adjust the valves of cylinder II.
- 10. Procede likewise for the remaining cylinders.
- Clean the rocker box covers with solvent and inspect the cork gasket. Replace the gasket if required.
- 12. Test the free movement of the ball check valve and correct deficiencies.
- 13. Install rocker box covers.
- 14. Start engine and check for oil leaks.